

Mine-ore-Mine

Wood Box Kit
14+ Age Group


Small Parts

CHOKING HAZARD

This kit and resulting product are not suitable for small children under 6 years


Sharp parts

Step 1




Punch out the tool,
...the tool is your freind.

Step 2




Punch out C1, both
C2s, and all four C3s.

Step 4




First assemble the sides.
Push C3 into C2 for both side panels.

Step 3




Press both side panels down into C1. Flip over
and press hard to fully seat the side panels.

Step 5




Punch out and separate C4, both C6s,
C7, C8, and both C9s.

Step 6




Push C4 into C9



Slot both C6s into C9




Slot C5 & C7 into C9.




Fit other C9 onto all pegs

Step 7



Push C8 into bottom slots

Sneak tabs under the top.



Tips & Tricks

- * Gluing is optional, but if you do, only put tiny amounts in the corners, stay away from the moving parts.
- * If the switches feel tight, try sanding the bumps just a little bit.
- * If the tray squeaks when sliding, try putting some wax on the bottom edges
- * If the tray is too tight when sliding, try sanding the bumps on the top of the tray, just a tiny bit at a time.
- * If the tray way out of spec due to receiving a thicker than normal sheet, you may need to sand the whole top of the tray down until a good fit is achieved

Your personal build experience will vary. Keep in mind you may have to sand and or glue certain parts of this kit if the wood is not co-operating. Our goal is for you to have a fun build experience. If you find that the kit is not building as well as you had hoped, i.e. tabs are too tight, or a part is broken or malformed, please let us know, we and will make it right.

<http://www.Orbitstation.com>

**Visit [OrbitStation.com](http://www.OrbitStation.com) for
more great kits and games.**

